




Ninja export version



Make the strap A -> B



ATTENTION
DO NOT
CONNECT
THIS POINT C

standard "RU" = 400 ch. 4W AM/FM
standard "PX" = 400 ch. 4W AM/FM freq. - 5KHz

See user manual how to change standards.